



## PORTERFIELD BRAKE PAD BREAK-IN TIPS 14-39100 & 14-39200

These are some general guidelines for breaking in the sport pads.

When you go out for your test drive, be forewarned that they will be very high effort at first. Do a few light stops to warm up the rotors, then do at least twenty fairly hard stops from 20-25 mph. Do this until the brakes actually fade somewhat, then drive back, letting the brakes cool off, and park the car WITH HANDBRAKE OFF, for an hour or so.

You're ready to roll!

Thank you for your purchase. If you have any questions during installation or suggestions for improvement to the product or the instructions - please don't hesitate to call or email.